

SO-3208

Denna instruktion gäller för nedanstående batteribackuper från Milleteknik.

- **SF-MO-5M** (Modell A)
- **SF-MO-5S** (Modell A)
- **SF-MO-10M** (Modell A)
- **SF-MO-10S** (Modell A)
- **SF-MO-25L** (Modell B)

Krav: Centralenhet SO-3208 med version 3.24 eller senare.

1. Byglarna J1 (terminering) och J2 (RS485 enable) på centralenheten ska vara kortslutna.
2. Batteribackupen måste ha RS485-adress 1, sätt DIP switch 1 till **ON**.
3. Anslut batteribackupen enligt nedan.
4. Konfigurera centralenheten.

Inkoppling

Kommunikation		
SO-3208 RS485	UPS Modell A	UPS Modell B
0V	P3:3 (GND)	P2:9 (-)
24V		
A	P3:1 (A/+)	P2:8 (RS485+)
B	P3:2 (B/-)	P2:7 (RS485-)

Konfigurering

1. Logga in i centralenheten som **systemanvändare**.
2. Gå till menyvalet System->Integration->UPS.
3. Aktivera integrationen och ange önskade värden under rubriken Milleteknik.
4. Starta om centralenheten genom att köra funktionen **Reboot SO-3208**.
Funktionen finns under menyvalet Verktyg->Databas.
5. När centralenheten åter igen är i drift presenteras information från batteribackupen på Hem-sidan.

SO-3208

This instruction applies to the below battery backups from Milletechnik.

- **SF-MO-5M** (Model A)
- **SF-MO-5S** (Model A)
- **SF-MO-10M** (Model A)
- **SF-MO-10S** (Model A)
- **SF-MO-25L** (Model B)

Requirement: Central unit SO-3208 with version 3.24 or later.

1. Jumpers J1 (termination) and J2 (RS485 enable) on the central unit must be closed.
2. The battery backup must have RS485 address 1, set DIP Switch 1 to ON.
3. Connect the battery backup as below.
4. Configure the central unit.

Connection

Communication		
SO-3208 RS485	UPS Model A	UPS Model B
0V	P3:3 (GND)	P2:9 (-)
24V		
A	P3:1 (A/+)	P2:8 (RS485+)
B	P3:2 (B/-)	P2:7 (RS485-)

SO-3208

Configuration

1. Log in to the central unit as a system user.
2. Go to the menu option System->Integration->UPS.
3. Activate the integration and enter the desired values under the heading Milletechnik.
4. Reboot the central unit by running the Reboot SO-3208 function.
5. The function can be found under the menu option Tools->Database.
6. When the central unit is operational again, information from the battery backup is presented on the Home page.